



A3 KEY FOB CONCEALMENT Style 1 Supplement

The Geonautics A3k concealment contains a Dingo audio recorder with an internal microphone for the purpose of covertly recording conversations.



GETTING STARTED

Remove the screw from the back of the unit. The unit should come apart into two halves, as shown below.



For best performance the device should be powered by three "High Drain" 399 (or SR927W) Silver Oxide Batteries, these will provide approximately 2 hours of recording.

"Low Drain" batteries (e.g. 395) will not provide this level of performance.

Insert 3 batteries in the battery holder provided within the device. The positive (+ve) terminal is towards the outside of the device, whilst the negative (-ve) terminal is the spring side. Once batteries have been inserted, the device is in "sleep" mode waiting for the ON sequence to begin recording.

MAKING A RECORDING

Press and hold either of the buttons (both buttons are connected together and offer the same functionality), for approximately 5 seconds until the LED on the face of the device turns ON (to indicate the recording has started), release the switch and the LED will turn off. Whilst the unit is recording, the LED will turn ON when either button is pressed. This allows the user to see if the device is recording at that time. This will not interfere with the audio being recorded.

ENDING A RECORDING

Press and hold either of the buttons for 20 seconds. The LED turns ON and when the LED turns OFF, this indicates that the device has stopped recording. Whilst the unit is OFF, the LED will not illuminate when either button is pressed. This allows the user to know that the device is not recording at that time.

CONNECTING THE A3 KEY FOB TO A PC

Plug the Geonautics Dongle into the USB port at the back of your PC. Plug the other end of the Geonautics Dongle into the connector located inside the unit, as can be seen opposite.



A3K KIT

Dingo Kit	Description
TAG-A3k Kit	TAG-A3k Digital recorder USB download cable (1.2m/ 4ft cable) 3 x v399 batteries Software for download & replay Bilby/Dingo User Guide Plastic Case

Notes: The Key Fob audio recorder **does not** contain the facility to conduct timer mode recordings. Please consult your Bilby/Dingo User Guide for more information on audio and software questions.