

SUPPLEMENT

A5RF CLIP2 HIDE



Geonautics

OVERVIEW The Geonautics A5RF Clip2 Hide contains an A5RF audio recorder within a JBL Clip2 Wireless Bluetooth Speaker. The A5RF operates even when the Bluetooth speaker is in operation.

USING The speaker contains a rechargeable battery that it and the A5RF both run from.

The unit operates as a standard A5RF device where the RF Switch feature can be programmed and utilised in the operation of the recorder.



The audio is ported through the housing direct from the standard microphone hole of the Clip2.

Mic Port

Please read the A5RF User Guide for more information on the operation of the standard A5RF devices features.

POWER Plugging in a standard micro USB cable to a power source will charge the internal battery. The speaker user guide indicates a charging time of 2½ hours from a 0.5Amp charger.

The A5RF is connected to the internal battery directly and if left on the shelf for an extended period of time, will drain the internal battery. Charging your unit fully prior to deployment is highly recommended.



A fully charged battery and the speaker left in the off state will allow the A5RF to record for 70+ hours.

DOWNLOADING An adaptor lead is provided in your Clip2 Hide Kit to allow you to connect the speaker's micro USB port to Whisper2 via a Dongle3 for configuration and downloading. The normal features of an A5RF will be accessible via the Whisper2 interface.



Note: The built in microphone of the Clip2 has been connected to the A5RF recorder so the hands free feature of the Clip2 is disabled.